


JS8Call - How do I call CQ?

Just click on the CQ button. JS8Call will put a CQ message in the message pane, you can type in more text if you want. (**NOTE** You don't need to enter your callsign, JS8Call will do that for you before the message is sent). JS8Call will start sending your CQ for you, unless you have disabled this option. In that case click the send button to send the message



You can configure what you want in your CQ message on the first page of JS8Call's settings

